

PIPELINE LEAK DETECTOR



v. 5.1

# **PLD2 Main View**

#### Download the latest PLD2 App from the App Store. Search for "PLD2".



www.sixtyfourseconds.com

## Let's Get Started...

Step 1: Turn on PLD2 Sensor Touch the key chain magnet to the

silver target label.

# O int PLD"

waterp

### Step 2: Start the WaterPoint PLD2 App

Tap the WP PLD App icon on the iPod touch/iPhone main screen.



#### Step 3: Link to PLD2 Sensor

In the PLD Recording view, make sure the PLD's serial number is entered correctly (1). Tap Link (2). The PLD target will turn red (3) and there will be a green dot next to the red target indicating that the PLD Sensor is linked to the PLD App.

	Sound	Index		
		Recordin	g Histo	cy 🕨
RECENT SAVED REC	ORDINGS	Last Tue	0	0
H275		10:57 AM Apr 17, 2021	215	() ()
H316	►	Apr 17, 2021	209	<u>(</u> )
H315	►	Apr 17, 2021	442	(1)
H312	►	Apr 17, 2021	68	(j)
H310	•	Apr 17, 2021	18	(
Question and		Disatis	0	
Contact Gro	und Pi	pe Plastic	Open	

Note: If you want to temporarily unlink with the PLD Sensor so that another device can link with the PLD Sensor, tap the Action button in the top right corner (4). Tap Unlink PLD. The green dot next to the PLD red target will turn yellow.

# Recording

Tap on the Record button to start recording (1). When the PLD is recording a red dot appears next to the Stop button which has replaced the Record button (2). Recording stops when you tap the Stop button or after 64 seconds.



Recordings longer than 4 seconds can be saved by tapping Save (3). Enter a custom name for the recording in the text box (4) then tap Save again. You may change the name of any saved recording at any time by tapping on the information icon next to the recording (5).

#### **Replaying Saved Recordings**

Tap on the row of a saved recording and it will play automatically. The Play button on the row is replaced by the Stop button which can be used to stop the recording at any time.

You can change the filters while listening to any saved recording.





## **Support Center**

Tap Support Center in the Action button drop down to send a support request directly to Support at 64seconds as well as access PLD guides.

	PLD2 64seconds Support Center			
Actors	64seconds monitors all support requests during the day. We'll get back to you within 24 hours, usually sooner.			
Listening Settings				
PLD Status	CREATE A SUPPORT REQUEST NOW			
- Eb Status	Subject Enter subject here			
Cloud Sync	Type or Speak Your Message			
Unlink PLD				
Support Center				
Cancel	Send to 64seconds			
	Sending a support request requires an internet connection and an active email account.			
	GUIDES			
	PLD Connection Guide >			
	PLD Recording Guide >			

## **Compatible iOS Devices**

The upgraded PLD2 is compatible with the following Apple iOS devices that have iOS 16 or later. *PLD2 will no longer work with any iPod touch*.

**iPhones:** 8, 8 Plus, X, XR, XS, XS Max, 11/12/13/14, 11/12/13/14 Pro, 11 Pro Max **iPads:** iPad mini (5th/6th gen); iPad (10th gen); iPad Air (3rd/4th/5th gen); iPad Pro 11″ (2018 -2022); iPad Pro 12.9″ (2018-2022)

## **Recharging the PLD Sensor Unit**

The PLD2 Sensor Unit recharges using the wall AC or auto DC power supplies included. While charging, the LED will flash until the unit is fully charged.



Note: WaterPoint PLD2 can be used within the WaterPoint Network (WPN2) app on an iPad or iPhone/iPod. The WPN2 app is available for free from the Apple App Store.

